

1	APPLICATION.....	2
2	DESCRIPTION (FIG A) .....	2
3	PACKAGE CONTENT LIST.....	2
4	SYMBOLS .....	2
5	GENERAL POWER TOOL SAFETY WARNINGS .....	3
5.1	<i>Working area</i> .....	3
5.2	<i>Electrical safety</i> .....	3
5.3	<i>Personal safety</i> .....	3
5.4	<i>Power tool use and care</i> .....	4
5.5	<i>Service</i> .....	4
6	SPECIAL SAFETY INSTRUCTIONS FOR POLISHING TOOL .....	4
7	OPERATION.....	5
8	CARE TIPS.....	6
9	TECHNICAL DATA .....	6
10	NOISE .....	6
11	MAINTENANCE .....	6
12	WARRANTY .....	7
13	ENVIRONMENT .....	7
14	DECLARATION OF CONFORMITY .....	8

# POLISHER 110W - 240MM POWX0496

## 1 APPLICATION

Your polishing tool was designed for polishing the painted surfaces of cars. Additional uses are not approved.



**WARNING! For your own safety, read this manual and the general safety instructions carefully before using the appliance. Your power tool should only be given to other users together with these instructions.**

## 2 DESCRIPTION (FIG A)

1. On/off switch
2. Grip
3. Polishing wheel
4. Ventilation slots

## 3 PACKAGE CONTENT LIST

- Remove all packaging materials.
- Remove remaining packaging and packing inserts (if included).
- Check that the package contents are complete.
- Check the appliance, the power cord, the power plug and all accessories for transportation damage.
- Keep the packaging materials as far as possible until the end of the warranty period. Then take it to your local waste disposal system.



**WARNING Packaging materials are not toys! Children must not play with plastic bags! There is a danger of suffocation!**

- 1tool
- Manual
- 1 clean woolen cloth for polisher
- 1 towel cover for polisher.



**If any parts are missing or damaged, please contact your dealer.**

## 4 SYMBOLS

The following symbols are used in this manual and/or on the tool:

	Denotes risk of personal injury or damage to the tool.		Read manual before use
	In accordance with essential safety standards of applicable European directives		Class II - The tool is double insulated; Earthing wire is therefore not necessary.

## 5 GENERAL POWER TOOL SAFETY WARNINGS

Read all safety warnings and instructions. Failure to heed warnings and follow instructions may result in electric shock, fire and/or serious injury. Keep safety warnings and instructions for future reference. The term "power tool" in the safety warnings refers to your mains-operated (corded) power tool or battery-operated (cordless) power tool.

### 5.1 Working area

- Keep working area clean and well lit. Untidy and dark areas can lead to accidents.
- Do not operate power tools in potentially explosive surroundings, for example, in the presence of inflammable liquids, gases or dust. Power tools create sparks which may ignite the dust or fumes.
- Keep children and bystanders at a distance when operating a power tool. Distractions can cause you to lose control of it.

### 5.2 Electrical safety



**Always check that the power supply corresponds to the voltage on the rating plate.**

- Power tool plugs must match the outlet. Never modify the plug in any way. Do not use adapter plugs with earthed power tools. Unmodified plugs and matching outlets will reduce the risk of a lethal electric shock.
- Avoid body contact with earthed surfaces such as pipes, radiators, kitchen ranges and refrigerators. There is an increased risk of a lethal electric shock if your body is earthed.
- Do not expose power tools to rain or wet conditions. If water gets inside a power tool, it will increase the risk of a lethal electric shock.
- Do not damage the cord. Never use the cord for carrying, pulling or unplugging the power tool. Keep the cord away from heat, oil, sharp edges or moving parts. Damaged or entangled cords increase the risk of a lethal electric shock.
- When operating a power tool outdoors, use an extension cable suitable for outdoor use. Using a cord suitable for outdoor use reduces the risk of a lethal electric shock.
- If operating a power tool in a damp location is unavoidable, use a power supply protected by a residual current device (RCD). Using an RCD reduces the risk of a lethal electric shock.

### 5.3 Personal safety

- Stay alert, watch what you are doing and use common sense when operating a power tool. Do not use a power tool when you are tired or under the influence of drugs, alcohol or medication. A moment of inattention when operating a power tool may result in serious personal injury.
- Use safety equipment. Always wear eye protection. Using safety equipment such as a dust mask, non-skid safety shoes, a hard hat, or hearing protection whenever it is needed will reduce the risk of personal injury.
- Avoid accidental starts. Ensure the switch is in the off position before inserting the plug. Carrying power tools with your finger on the switch or plugging in power tools when the switch is in the on position makes accidents more likely.
- Remove any adjusting keys or spanners before turning on the power tool. A spanner or key left attached to a rotating part of the power tool may result in personal injury.
- Do not reach out too far. Keep your feet firmly on the ground at all times. This will enable you retain control over the power tool in unexpected situations.
- Dress properly. Do not wear loose clothing or jewellery. Keep your hair, clothing and gloves away from the power tool. Loose clothes, jewellery or long hair can become entangled in the moving parts.

- If there are devices for connecting dust extraction and collection facilities, please ensure that they are attached and used correctly. Using such devices can reduce dust-related hazards.

#### **5.4 Power tool use and care**

- Do not expect the power tool to do more than it can. Use the correct power tool for what you want to do. A power tool will achieve better results and be safer if used in the context for which it was designed.
- Do not use the power tool if the switch cannot turn it on and off. A power tool with a broken switch is dangerous and must be repaired.
- Disconnect the plug from the power source before making adjustments, changing accessories, or storing power tools. Such preventive safety measures reduce the risk of starting the power tool accidentally.
- Store power tools, when not in use, out of the reach of children and do not allow people who are not familiar with the power tool or these instructions to operate it. Power tools are potentially dangerous in the hands of untrained users.
- Maintenance. Check for misalignment or jammed moving parts, breakages or any other feature that might affect the operation of the power tool. If it is damaged, the power tool must be repaired. Many accidents are caused by using poorly maintained power tools.
- Keep cutting tools sharp and clean. Properly maintained cutting tools with sharp cutting edges are less likely to jam and are easier to control.
- Use the power tool, accessories and cutting tools, etc., in accordance with these instructions and in the manner intended for the particular type of power tool, taking into account the working conditions and the work which needs to be done. Using a power tool in ways for which it was not intended can lead to potentially hazardous situations.

#### **5.5 Service**

- Your power tool should be serviced by a qualified specialist using only standard spare parts. This will ensure that it meets the required safety standards.

## **6 SPECIAL SAFETY INSTRUCTIONS FOR POLISHING TOOL**


- Use the polishing tool only in a clean and dry environment.
- The polishing tool should be placed on the intended surface before being switched on or off.
- Keep children away by taking the appropriate precautions.
- Avoid switching on the tool accidentally.
- If the tool is plugged into the mains keep your finger off the switch when carrying the tool from one place to another.
- Never carry or pull the tool by its power cable.
- Protect the cable from heat, oil and sharp edges.
- Check the cable for damage before each use.
- Do not apply too much pressure when polishing, but simply allow the tool to glide over the surface.
- Check the housing and switch for damage.
- Do not use the polishing tool if the housing or switch is defective.

## 7 OPERATION


- Switching on and off (fig. A)
- To switch the tool on, set the on/off switch (1) to 'I'.
- To switch the tool off, set the on/off switch (1) to 'O'.




**When using wax and polishes, please observe the manufacturers' instructions**




Pull the textile polishing cap over the polishing pad. Make sure the polishing cap is completely clean.




Spread the polish evenly over the polishing pad. Do not apply the polish directly to the car bodywork




Switch the tool on and off only when it is resting on the car bodywork.




Place the mains cable over your shoulder and work first on large, flat surfaces such as the bonnet, boot lid and roof. Keep your movements as regular as possible. Important! Allow the polishing tool to glide over the polishing surface. Do not apply pressure !



Next work on the smaller surfaces (doors, for example). Allow the mains cable to hang from the appliance and hold the tool as illustrated.



For the areas that cannot be easily reached (for example, rear view mirrors, bumpers and door handles) remove the polishing cover and polish these areas by hand.



Now replace the textile polishing cap with the fine polishing cap and stretch the latter over the polishing pad. Make sure it is completely clean. Remove the layer of polish in the same order as it was applied.  
Important! Do not apply pressure on the polishing tool!

## 8 CARE TIPS

- For optimum paintwork protection, you should polish your car 2 to 3 times a year.
- Wash your car at least every 2 weeks. Avoid using household detergents as these can damage the paintwork and remove the layer of wax.
- Wash your car with a clean sponge, working from top to bottom.
- Remove all insects, bird droppings and tar stains from the paintwork daily.
- If you use any window-cleaning agents, spray them onto a cloth and not directly onto the windows to prevent them wetting the paintwork.



**CAUTION: Do not polish in direct sunlight or allow polish to be baked dry on your car.**

## 9 TECHNICAL DATA

Rated voltage	220-240V
Rated frequency	50Hz
Rated input	110W
Protection class	II
Rotation speed	3100min <sup>-1</sup>
Weight	2.4kg
Disc Diameter	Ø240mm

## 10 NOISE

Noise emission values measured according to relevant standard. (K=3)

Acoustic pressure level LpA	60 dB(A)
Acoustic power level LwA	71 dB(A)



**ATTENTION! Wear hearing protection when sound pressure is over 85 dB(A).**

aw (Vibration):	11.5 m/s <sup>2</sup>	K = 1.5 m/s <sup>2</sup>
-----------------	-----------------------	--------------------------

## 11 MAINTENANCE

- The tool requires no special maintenance.
- Regularly clean the ventilation slots.
- Regularly wash the polishing covers. Wash them by hand only and leave them to dry in the air.
- If you do not plan to use the tool for an extended period of time, remove the polishing cover from the polishing wheel. Store the tool with the polishing wheel pointing up.

## 12 WARRANTY

- This product is warranted for a 36-month period effective from the date of purchase by the first user.
- This warranty covers all material or production flaws excluding : batteries, chargers, defective parts subject to normal wear & tear such as bearings, brushes, cables, and plugs, or accessories such as drills, drill bits, saw blades, etc. ; damage or defects resulting from maltreatment, accidents or alterations; nor the cost of transportation.
- Damage and/or defects resulting from inappropriate use also do not fall under the warranty provisions.
- We also disclaim all liability for any bodily injury resulting from inappropriate use of the tool.
- Repairs may only be carried out by an authorised customer service centre for Powerplus tools.
- You can always obtain more information at the number 00 32 3 292 92 90.
- Any transportation costs shall always be borne by the customer, unless agreed otherwise in writing.
- At the same time, no claim can be made on the warranty if the damage of the device is the result of negligent maintenance or overload.
- Definitely excluded from the warranty is damage resulting from fluid permeation, excessive dust penetration, intentional damage (on purpose or by gross carelessness), inappropriate usage (use for purposes for which the device is not suitable), incompetent usage (e.g. not following the instructions given in the manual), inexpert assembly, lightning strike, erroneous net voltage. This list is not exhaustive.
- Acceptance of claims under warranty can never lead to the prolongation of the warranty period nor commencement of a new warranty period in case of a device replacement.
- Devices or parts which are replaced under the warranty therefore remain the property of Varo NV.
- We reserve the right to reject a claim whenever the purchase cannot be verified or when it is clear that the product has not been properly maintained. (Clean ventilation slots, carbon brushes serviced regularly, etc.).
- Your purchase receipt must be kept as proof of date of purchase.
- Your appliance must be returned undismantled to your dealer in an acceptably clean state, (in its original blow-moulded case if applicable to the unit), accompanied by proof of purchase.

## 13 ENVIRONMENT



Should your appliance need replacement after extended use, do not dispose of it with the household refuse, but in an environmentally safe way.

Please dispose of used motor oil in a manner that spares the environment. We suggest you take it in a sealed container to your local service station for recycling. Do not throw it into the trash or pour it on the ground

**14 DECLARATION OF CONFORMITY**



**VARO – Vic. Van Rompuy N.V.** - Joseph Van Instraat 9 - BE2500 Lier - BELGIUM,  
declares that,  
product: POLISHING TOOL  
trade mark: POWERplus  
model: POWX0496

is in conformity with the essential requirements and other relevant provisions of the applicable European Directives, based on the application of European harmonized standards. Any unauthorized modification of the apparatus voids this declaration.

European Directives (including, if applicable, their amendments up to the date of signature);  
2011/65/EU  
2006/42/EC  
2014/30/EU

European harmonized standards (including, if applicable, their amendments up to the date of signature);  
EN62841-1 : 2015  
EN62841-2-4 : 2014  
EN55014-1 : 2017  
EN55014-2 : 2015  
EN61000-3-2 : 2014  
EN61000-3-3 : 2013

Keeper of the Technical Documentation : Philippe Vankerkhove, VARO – Vic. Van Rompuy N.V.

The undersigned acts on behalf of the company CEO,

Philippe Vankerkhove  
Regulatory Affairs – Compliance Manager  
15/10/2020, Lier - Belgium